O S T E R M A N Infino NH-1029 LOTTE ADVANCED MATERIALS CO., LTD. - Polycarbonate + ABS

Thursday, September 29, 2016

General Information						
General						
Material Status	Commercial: Active					
Availability	 Africa & Middle East Asia Pacific	EuropeLatin America	North America			
Features	Flame Retardant					

ASTM & ISO Properties ¹					
Physical	Nominal Value	Unit	Test Method		
Specific Gravity (Natural)	1.19		ASTM D792		
Melt Mass-Flow Rate (MFR) (220°C/10.0 kg)	110	g/10 min	ASTM D1238		
Mechanical	Nominal Value	Unit	Test Method		
Tensile Strength ² (Yield)	8560	psi	ASTM D638		
Flexural Modulus ³	348000	psi	ASTM D790		
Flexural Strength ³	12800	psi	ASTM D790		
Impact	Nominal Value	Unit	Test Method		
Notched Izod Impact (73°F, 0.125 in)	7.3	ft·lb/in	ASTM D256		
Hardness	Nominal Value	Unit	Test Method		
Rockwell Hardness (R-Scale)	115		ASTM D785		
Thermal	Nominal Value	Unit	Test Method		
Vicat Softening Temperature	194	°F	ISO 306/B50		
Flammability	Nominal Value	Unit	Test Method		
Flame Rating			UL 94		
0.05 in	V-1				
0.06 in	V-0				
0.12 in	V-0				

Processing Information				
Injection	Nominal Value	Unit		
Drying Temperature				
	176	°F		
Desiccant Dryer	176	°F		
Drying Time				
	4.0	hr		
Desiccant Dryer	2.0	hr		
Suggested Max Moisture	0.030	%		
Rear Temperature	356 to 428	°F		
Middle Temperature	428 to 464	°F		
Front Temperature	428 to 482	°F		
Nozzle Temperature	446	°F		
Mold Temperature	122 to 194	°F		
Injection Pressure	14200	psi		
Back Pressure	145	psi		
Screw Speed	30	rpm		

LEGAL DISCLAIMER: Before using a product sold by Osterman, users should make their own independent determination that the product is suitable for the intended use and can be used safely and legally. SELLER MAKES NO WARRANTY; EXPRESS OR IMPLIED (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY WARRANTY) OTHER THAN AS SEPARATELY AGREED TO BY THE PARTIES IN A CONTRACT. This product(s) may not be used in: (i) any U.S. FDA Class I, Health Canada Class I, and/or European Union Class I medical devices; without prior written approval by Seller for each specific product and application; or (ii) the manufacture of any of the following, without prior written approval by Seller for each specific product and application; U.S. FDA Class II Medical Devices; Health Canada Class II or Class III Medical Devices; European Union Class I Medical Devices; flexip or yource packaging that is considered a part or component of one of the aforemationed medical devices; packaging in direct contact with a pharmaceutical active ingredient and/or dosage form that is intended for inhalation, injection, intravenous, nasal, ophthalmic (eye), digestive, or topical (skin) administration; and tobase for the divide applications: 4. Medical Devices; European Class III Medical Devices; (ii) applications involving permanent implantation into the body; (iii) life-sustaining medical applications; and (iv) lead, asbestos or MTBE related applications. All references to U.S. FDA, Health Canada, and European Union regulations include another country's equivalent regulatory classification.

Injection Notes

Hot Runner Manifold Temperature: 240°C Hot Runner Valve Nozzle Temperature: 240°C

Notes

¹ Typical properties: these are not to be construed as specifications.

² 2.0 in/min

³ 0.11 in/min

LEGAL DISCLAIMER: Before using a product sold by Osterman, users should make their own independent determination that the product is suitable for the intended use and can be used safely and legally. SELLER MAKES NO WARRANTY; EXPRESS OR IMPLIED (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY WARRANTY) OTHER THAN AS SEPARATELY AGREED TO BY THE PARTIES IN A CONTRACT. This product(s) may not be used in: (i) any U.S. FDA Class I, that Canada Class I, and/or European Union Class I medical devices; without prior written approval by Seller for each specific product and application: U.S. FDA Class II Medical Devices; Health Canada Class II or Class III Medical Devices; European Union Class I Medical Devices; film, overwrap and/or product packaging that is considered a part or component of one of the aforementioned medical devices; packaging in direct contact with a pharmaceutical active ingredient and/or dosage form that is intended for inhalation, injection, intravenous, nasal, ophthalmic (eye), digestive, or topical (skin) administration; and tobase for products and applications. Additionally, the product(s) may not be used in: (i) U.S. FDA Class III Medical Devices; Health Canada Class IV Medical Devices; European Class III Medical Devices; Health Canada Class IV Medical Devices; European Class III Medical Devices; Health Canada Class IV Medical Devices; European Class III Medical Devices; Health Canada Class IV Medical Devices; European Class III Medical Devices; Health Canada Class IV Medical Devices; European Class III Medical Devices; (ii) applications involving permanent implantation into the body; (iii) Ilffe-sustaining medical applications; and (iv) lead, asbestos or MTBE related applications. All references to U.S. FDA, Health Canada, and European Union regulations include another country's equivalent regulatory classification.