

TEGO® Alkanol S 2 P  
TEGO® Alkanol S 20 P  
TEGO® Alkanol S 21 P  
TEGO® Alkanol L 23 P

- Emulsifiers for the formulation of cosmetic O/W and W/O emulsions
- Suitable for the preparation of antiperspirants
- Stable emulsions at a wide pH range

Personal Care

## INCI names (CTFA names)

TEGO® Alkanol S 2 P	Steareth-2
TEGO® Alkanol S 20 P	Steareth-20
TEGO® Alkanol S 21 P	Steareth-21
TEGO® Alkanol L 23 P	Laureth-23

Chemical and physical properties (not part of specifications)	TEGO® Alkanol S 2 P	TEGO® Alkanol S 20 P	TEGO® Alkanol S 21 P	TEGO® Alkanol L 23 P
Form	pellets	pellets	pellets	pellets
HLB value	approx. 5	approx. 15	approx. 15	approx. 17

### Properties

- TEGO® Alkanol S 2 P, S 20 P, S 21 P and L 23 P are non-ionic emulsifiers based on vegetable raw materials.
- Both hydrophilic and lipophilic types are effective in either O/W or W/O emulsions. In combination with other emulsifiers creams and lotions can be formulated.
- The amount used, referred to the emulsion, is 1.0 – 6.0 %.
- TEGO® Alkanol S 2 P, S 20 P, S 21 P or L 23 P should be used in combination with consistency-providing substances for the formation of viscosity-enhancing gel structures in the external water phase. TEGO® Alkanol 16, 18 or 1618 have proved most effective. These form liquid-crystalline structures in the water phase, the viscosity of the external phase is increased and the emulsion is stabilized.
- A rheological additive such as TEGO® Carbomer 134, 141 or 341 ER should be added to increase the thermo-stability of the emulsion.
- TEGO® Alkanol S 2 P, S 20 P, S 21 P or L 23 P emulsify oils and fats in highly acidic or alkaline media.

### Preparation

We recommend melting TEGO® Alkanol S 2 P, S 20 P, S 21 P or L 23 P together with the oil phase. Further manufacturing conditions correspond to the principles of common processing for O/W or W/O emulsions.

### Application

TEGO® Alkanol S 2 P, S 20 P, S 21 P or L 23 P are suitable for

- O/W skin care creams and lotions
- W/O skin care creams and lotions
- Deodorant and antiperspirant sprays and roll-ons
- Hair conditioner
- Wet wipes

### Recommended usage concentration

1.0 – 6.0 %

### Packaging

TEGO® Alkanol S 2 P  
450 kg pallet (18 x 25 kg carton box)

TEGO® Alkanol S 20 P  
600 kg pallet (24 x 25 kg bag)

TEGO® Alkanol S 21 P  
600 kg pallet (24 x 25 kg bag)

TEGO® Alkanol L 23 P  
600 kg pallet (24 x 25 kg bag)

### Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transportation and for dangerous substances
- protective measures for storage and handling
- measures in case of accidents and fires
- toxicity and ecological effects

is given in our material safety data sheets.

## Guide Line Formulations

<b>O/W Skin Repair Cream WR 1/00-11</b>	
<b>Phase A</b>	
TEGO® Alkanol S 2 P	2.40 %
TEGO® Alkanol S 20 P	0.60 %
TEGO® Alkanol 1618 (Cetearyl Alcohol)	3.00 %
Stearic Acid	1.00 %
TEGOSOFT® APS (PPG-11 Stearyl Ether)	3.00 %
Isohexadecane	6.00 %
Cyclomethicone	1.00 %
<b>Phase B</b>	
Glycerin	3.00 %
SK-influx (Ceramide NP; Ceramide AP; Ceramide EOP; Phytosphingosine; Cholesterol; Sodium Lauroyl Lactylate; Carbomer; Xanthan Gum)	5.00 %
Water	73.60 %
<b>Phase C</b>	
TEGO® Carbomer 134 (Carbomer)	0.20 %
Mineral Oil	0.80 %
<b>Phase D</b>	
Sodium Hydroxide (10 % in water)	0.40 %
Preservative, Perfume	q.s.
<b>Preparation:</b>	
<ol style="list-style-type: none"> <li>1. Heat phase A and B separately to approx. 80 °C.</li> <li>2. Add phase A to phase B with stirring.<sup>1)</sup></li> <li>3. Homogenise.</li> <li>4. Cool with gentle stirring to approx. 60 °C and add phase C.</li> <li>5. Homogenise for a short time.</li> <li>6. Cool with gentle stirring and add phase D below 40 °C.</li> </ol>	
<sup>1)</sup> Important: If phase A has to be charged into the vessel first, phase B must be added <b>without stirring</b> .	

<b>O/W Deodorant Roll-on UP 41.3/04</b>	
<b>Phase A</b>	
TEGO® Alkanol S 2 P	2.20 %
TEGO® Alkanol S 20 P	1.00 %
TEGOSOFT® liquid (Cetearyl Ethylhexanoate)	2.00 %
TEGOSOFT® APS (PPG-11 Stearyl Ether)	2.00 %
ABIL® 350 (Dimethicone)	0.50 %
TEGO® Cosmo P 813 (Polyglyceryl-3 Caprylate)	0.50 %
<b>Phase B</b>	
Glycerin	3.00 %
Water	88.50 %
<b>Phase C</b>	
Perfume	0.30 %
<b>Phase D</b>	
Citric Acid (50 % in water)	q.s.
<b>Phase E</b>	
Preservative	q.s.
<b>Preparation:</b>	
<ol style="list-style-type: none"> <li>1. Heat phase A and B separately to approx. 80 °C.</li> <li>2. Add phase A to phase B with stirring.<sup>1)</sup></li> <li>3. Homogenise.</li> <li>4. Cool with gentle stirring to approx. 40 °C and add phase C.</li> <li>5. Cool with gentle stirring below 30 °C.</li> <li>6. Adjust the pH to 5 - 6 with phase D.</li> </ol>	
<sup>1)</sup> Important: If phase A has to be charged into the vessel first, phase B must be added <b>without stirring</b> .	

E 01/12

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments.

The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used.  
(Status: April, 2008)