

TEGOSOFT® PSE 141 G

Co-emulsifier with re-fatting and moisturizing properties

- PEG-free, based on natural renewable raw materials
- Recommended usage concentration of 2 5 %
- Co-emulsifier for O/W creams and lotions

Personal Care

INCI name (CTFA name)

Sucrose Stearate

Chemical and physical properties (not part of specifications)	
Form	Pellets/Pellet

Conglomerates*

*Note: Conglomerates can form due to filling temperature and packaging pressure.

Application

- TEGOSOFT® PSE 141 G is produced from natural renewable raw materials.
- TEGOSOFT® PSE 141 G is a mild, PEG-free coemulsifier for O/W creams and lotions.
- TEGOSOFT® PSE 141 G has re-fatting and moisturizing properties.
- TEGOSOFT® PSE 141 G does not contain any solvent or preservative.

Preparation

It is suggested to add TEGOSOFT® PSE 141 G to the water phase. It is also possible to add TEGOSOFT® PSE 141 G to the oil phase.

Further manufacturing conditions correspond to the principles of common processing for O/W emulsions.

Application

 $\mathsf{TEGOSOFT}^{\bullet}$ PSE 141 G is especially suitable for O/W creams and lotions for

- Facial and Body Care
- After Sun Care
- Baby Care

Recommended usage concentration

2.0 - 5.0 % TEGOSOFT® PSE 141 G

Packaging

450 kg pallet (18 x 25 kg)

Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transport and for dangerous substances
- · protective measures for storage and handling
- · measures in case of accidents and fires
- toxicity and ecological effects

is given in our material safety data sheets.

Guide Line Formulations

O/W Moisturizing Body Lotion F 2/01-5	
Phase A	
TEGIN® 4100 Pellets (Glyceryl Stearate)	0.5 %
Stearic Acid	0.5 %
TEGOSOFT® MM (Myristyl Myristate)	1.0 %
TEGOSOFT® APM (PPG-3 Myristyl Ether)	3.0 %
TEGOSOFT® OP (Ethylhexyl Palmitate)	4.2 %
Cyclomethicone	5.0 %
Tocopheryl Acetate	0.5 %
ABIL® 350 (Dimethicone)	0.3 %
Phase B	
TEGO® Care CG 90 (Cetearyl Glucoside)	1.0 %
TEGOSOFT® PSE 141 G	2.0 %
Allantoin	0.2 %
Panthenol	0.5 %
Glycerin	3.0 %
Water	77.3 %
Phase C	
TEGO® Carbomer 141 (Carbomer)	0.2 %
TEGOSOFT® OP (Ethylhexyl Palmitate)	0.8 %
Phase D	
Sodium Hydroxide (10 % in water)	q.s.
Preservative, Parfum	q.s.

Preparation:

- 1. Heat phase A and B separately to approx. 80 °C.
- 2. Add phase A to phase B with stirring.1)
- 3. Homogenise.4. Cool with gentle stirring to approx. 60 °C and add phase C.
- 5. Homogenise for a short time.
- 6. Cool with gentle stirring and add phase D below 40 °C.

Facial Mask	
F 4/01-1	
Phase A	
ABIL® Care 85	1.5 %
(Bis-PEG/PPG-16/16 PEG/PPG-16/16	
Dimethicone; Caprylic/Capric	
Triglyceride)	
TEGINACID® C (Ceteareth-25)	1.0 %
TEGIN® M Pellets (Glyceryl Stearate)	3.5 %
TEGO® Alkanol 18 (Stearyl Alcohol)	2.0 %
Stearic Acid	1.0 %
TEGOSOFT® MM (Myristyl Myristate)	1.5 %
TEGOSOFT® DO (Decyl Oleate)	6.0 %
TEGOSOFT® TN	8.5 %
(C12-15 Alkyl Benzoate)	
Sweet Almond (Prunus Dulcis) Oil	5.0 %
Phase B	
TEGOSOFT® PSE 141 G	2.0 %
Glycerin	3.0 %
Panthenol	0.5 %
Allantoin	0.2 %
Water	60.8 %
Phase C	
TEGO® Carbomer 134 (Carbomer)	0.1 %
Mineral Oil (30 mPas)	0.4 %
Phase D	
Sodium Hydroxide (10 % in water)	q.s.
Preservative, Parfum	q.s.

Preparation:

- 1. Heat phase A and B separately to approx. 80 °C.
- 2. Add phase A to phase B with stirring.1)
- 3. Homogenise.
- 4. Cool with gentle stirring to approx. 60 °C and add phase C.
- 5. Homogenise for a short time.
- 6. Cool with gentle stirring and add phase D below 40 °C.

¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

O/W Body Souffle Cream		
MK 77/06-4		
Phase A		
AXOL® C 62 Pellets	1.50 %	
(Glyceryl Stearate Citrate)		
TEGIN® M Pellets (Glyceryl Stearate)	2.00 %	
TEGO® Alkanol 1618 (Cetearyl Alcohol)	3.00 %	
TEGOSOFT® DEC	20.00 %	
(Diethylhexyl Carbonate)		
Phase B		
TEGOSOFT® PSE 141 G	1.00 %	
Glycerin	3.00 %	
Water	67.70 %	
Phase C		
TEGO® Carbomer 341 ER	0.20 %	
(Acrylates / C10-30 Alkyl Acrylates		
Crosspolymer)		
TEGOSOFT® DEC	0.80 %	
(Diethylhexyl Carbonate)		
Phase D		
Sodium Hydroxide (10 % in water)	q.s.	
Phase E		
TEGO® Betain 810	0.80 %	
Preservative, Parfum	q.s.	

Preparation:

- 1. Heat phase A and B separately to 80 °C.
- 2. Add phase A to phase B with stirring.1)
- 3. Homogenise.
- 4. Cool with gentle stirring to approx. 60 °C and add phase C.
- 5. Homogenise for a short time.
- 6. Cool with gentle stirring and add phase D and E below 40 °C.

O/W Day Cream with UV A and UV B Protection Ma 58/01-2		
Phase A		
TEGO° Care 450	3.0 %	
(Polyglyceryl–3 Methylglucose		
Distearate)		
TEGIN® M Pellets (Glyceryl Stearate)	1.4 %	
TEGO® Alkanol 18 (Stearyl Alcohol)	0.6 %	
TEGOSOFT® CT	6.0 %	
(Caprylic/Capric Triglyceride)		
TEGOSOFT® TN	7.0 %	
(C12-15 Alkyl Benzoate)		
TEGOSOFT® PSE 141 G	1.0 %	
Avocado Oil	2.0 %	
Polysilicone-15	3.0 %	
(Parsol SLX, Roche)		
Bis-Ethylhexyloxyphenol	1.0 %	
Methoxyphenyl Triazine		
(Tinosorb S, Ciba)		
Butyl Methoxydibenzoylmethane	1.0 %	
Phase B		
Glycerin	3.0 %	
Water	71.0 %	
Phase Z		
Preservative, Parfum	q.s.	

Preparation:

- 1. Heat phase A and B separately to 70 75 °C.
- 2. Add phase A to phase B with stirring.1)
- 3. Homogenise.
- 4. Cool with gentle stirring.

¹⁾Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.

H 08/07

Especially concerning Active Ingredients

This product information is not intended to provide legal or regulatory advice about product uses or claims in any jurisdiction and should not be relied upon for such guidance (especially in the United States, Canada, and Mexico). Since global regulatory requirements differ, parties accessing this information are solely responsible for determining whether the products and/or claims comply with applicable local laws and regulations, including but not limited to import and export regulations. Please contact your local Evonik representative for more product information. Evonik assumes no liability for any use of our products that is not in compliance with the requirements of the country of the user.

This information and all further technical advice are based on Evonik Goldschmidt GmbH's present knowledge and experience. However, Evonik Goldschmidt GmbH assumes no liability for providing such information and advice including the extent to which such information and advice may relate to existing third party intellectual property rights, especially patent rights. In particular, Evonik Goldschmidt GmbH disclaims all CONDITIONS AND WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY. EVONIK GOLDSCHMIDT GMBH SHALL NOT BE RESPONSIBLE FOR CONSEQUENTIAL, INDIRECT OR INCIDENTAL DAMAGES (INCLUDING LOSS OF PROFITS) OF ANY KIND. Evonik Goldschmidt GmbH reserves the right to make any changes according to technological progress or further developments. It is the customer's responsibility and obligation to carefully inspect and test any incoming goods. Performance of the product(s) described herein should be verified by testing and carried out only by qualified experts. It is the sole responsibility of the customer to carry out and arrange for any such testing. Reference to trade names used by other companies is neither a recommendation, nor an endorsement of any product and does not imply that similar products could not be used. (Status: February, 2008)



¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring.