

## Mikrokill® COS (patented)

# Broad Spectrum Preservation System



**INCI Name:** Phenoxyethanol & Caprylyl Glycol & Chlorphenesin

**SAP Code#:** 137520

## Key Product Benefits

- Safe and effective
- Highly effective antimicrobial
- Broad spectrum activity on bacteria, yeast and mold
- Has a wide range of global regulatory acceptance
- Can be used alone or in combination with other preservatives
- Stable in the usual operating range for Personal Care products (pH 3-8)
- Compatible in a wide range of skin care, hair care and sun care systems
- Low odor profile
- Not tested on animals
- Liquid for ease of use
- Well documented safety profile
- Patented formula (US Patent No. US7854940)

## Recommended Use Level

0.75–1.5%

## Description

Mikrokill® COS is a unique, patented combination of three components (Phenoxyethanol, Chlorphenesin and Caprylyl Glycol), which are well accepted in a wide range of personal care products. Phenoxyethanol is a widely used and versatile preservative. Chlorphenesin is a known broad spectrum preservative and the inclusion of Caprylyl Glycol contributes biological synergism with moisturizing and wetting capabilities.

## Compositional Breakdown

Chemical Compound Breakdown	CAS No.	EINECS No.
Phenoxyethanol	122-99-6	204-589-7
Caprylyl Glycol	1117-86-8	214-254-7
Chlorphenesin	104-29-0	203-192-6

Chemical Compound Breakdown	%
Phenoxyethanol	62–66%
Caprylyl Glycol	18–22%
Chlorphenesin	13–19%

## Applications

- Anhydrous
- Baby care
- Baby wipes
- Body Butter
- Body wash
- Conditioner
- Cream
- Deo/Anti-Perspirant
- Eye creams/gels
- Eye shadow
- Face Lotion
- Face wipes
- Facial Cream
- Foundation
- Hair gel
- Hand soap (non anti-bac)
- Lipstick/gloss
- Lotion
- Make up remover
- Mascara
- Oil in Water
- Powder
- Shampoo
- Suncare
- Toner
- Water in Oil

## Efficacy

### Microbiological Challenge Studies

Studies were run on four formulas using a 0.75% concentration of Mikrokill® COS. The protocol used was a modification of the Cosmetic, Toiletry and Fragrance Association (CTFA) Challenge test using a 3 week re-challenge time period instead of a 4 week period. All samples were inoculated at the beginning of the study, sampled at 24 hours, 7 days, 14 days and 21 days. The samples were diluted in neutralizer and plated quantitatively for viable organisms at all sampling times. After 21 days, all samples were re-inoculated and subjected to a second challenge.

## Water in Oil Emulsion Cream (KKL9 – 137) Base Formulation

pH: n/a

% water: 75%; A<sub>w</sub>: n/a

Ingredient	%
<b>Phase A</b>	
DI-Water	q.s. to 100
Glycerin	3.00
Sodium Chloride	1.00

<b>Phase B</b>	
SF1328	10.00
SF 1202	8.50
Gel Base BSM-PT	2.50

## Test Results

### Colony Forming Units per Gram (CFU/g)

Test Organism	Unpreserved Control				Test-Mikrokill® COS (0.75%)			
	Initial Challenge			Rechallenge	Initial Challenge			Rechallenge
	24 hrs	7 days	21 days	21 days	24 hrs	7 days	21 days	21 days
<i>S. aureus</i>	1.1x10 <sup>5</sup>	1.5x10 <sup>2</sup>	<10	<10	<10	<10	<10	<10
<i>P. aeruginosa</i> + <i>B. cepacia</i>	5.1x10 <sup>4</sup>	4.2x10 <sup>2</sup>	<10	<10	<10	<10	<10	<10
<i>K. pneumoniae</i>	5.2x10 <sup>4</sup>	<10	<10	<10	<10	<10	<10	<10
<i>C. albicans</i>	7.0x10 <sup>3</sup>	3.2x10 <sup>2</sup>	8.1x10 <sup>2</sup>	5.5x10 <sup>3</sup>	<10	<10	<10	<10
<i>A. niger</i> + <i>Penicillium sp.</i>	1.6x10 <sup>3</sup>	7.0x10 <sup>3</sup>	3.8x10 <sup>2</sup>	3.7x10 <sup>2</sup>	6.0x10	<10	<10	<10

## Oil in Water Emulsion (AR5-026) Base Formulation

pH: 5

% water: 69.5%; A<sub>w</sub>: n/a

Ingredient	%
<b>Phase A</b>	
DI-Water	q.s. to 100
Glycerin	5.00

<b>Phase B</b>	
Cetearyl Alcohol & Cetareth-20	4.50
GMS 165	4.00
Mineral Oil	17.00

## Test Results

### Colony Forming Units per Gram (CFU/g)

Test Organism	Unpreserved Control				Test-Mikrokill® COS (0.75%)			
	Initial Challenge			Rechallenge	Initial Challenge			Rechallenge
	24 hrs	7 days	21 days	21 days	24 hrs	7 days	21 days	21 days
<i>S. aureus</i>	1.1x10 <sup>6</sup>	1.4x10 <sup>4</sup>	4.0x10	<10	2.5x10 <sup>2</sup>	<10	<10	<10
<i>P. aeruginosa</i> + <i>B. cepacia</i>	1.2x10 <sup>6</sup>	2.8x10 <sup>6</sup>	8.0x10 <sup>6</sup>	8.2x10 <sup>6</sup>	<10	<10	<10	<10
<i>K. pneumoniae</i>	1.6x10 <sup>6</sup>	1.1x10 <sup>5</sup>	1.5x10 <sup>2</sup>	3.2x10 <sup>5</sup>	<10	<10	<10	<10
<i>C. albicans</i>	1.7x10 <sup>5</sup>	2.0x10 <sup>5</sup>	2.7x10 <sup>5</sup>	7.2x10 <sup>4</sup>	<10	<10	<10	<10
<i>A. niger</i> + <i>Penicillium sp.</i>	3.3x10 <sup>4</sup>	3.3x10 <sup>4</sup>	3.4x10 <sup>4</sup>	7.2x10 <sup>4</sup>	4.3x10 <sup>4</sup>	<10	<10	<10

## Hair Conditioner (AR5-024) - Base Formulation

pH: 4.9

% water: 71.2%; A<sub>w</sub>: n/a

Ingredient	%
<b>Phase A</b>	
DI-Water	q.s. to 100
Hydroxyethylcellulose	0.30
<b>Phase B</b>	
Cetrimonium Bromide & Cetearyl Alcohol	1.00
Cetyl Alcohol	2.50
Stearyl Alcohol	1.00
Steareth-21	2.50
<b>Phase C</b>	
Polysorbate 80	0.50
Lecithin	1.00
Water	20.00

## Test Results

### Colony Forming Units per Gram (CFU/g)

Test Organism	Unpreserved Control				Test-Mikrokill® COS (0.75%)			
	Initial Challenge			Rechallenge	Initial Challenge			Rechallenge
	24 hrs	7 days	21 days	21 days	24 hrs	7 days	21 days	21 days
<i>S. aureus</i>	<10 <sup>3</sup>	<10	<10	<10	<10	<10	<10	<10
<i>P. aeruginosa</i> + <i>B. cepacia</i>	4.6x10 <sup>5</sup>	2.9x10 <sup>7</sup>	1.3x10 <sup>7</sup>	<10 <sup>7</sup>	<10	<10	<10	<10
<i>K. pneumoniae</i>	6.0x10 <sup>3</sup>	<10	<10	<10	<10	<10	<10	<10
<i>C. albicans</i>	9.8x10 <sup>4</sup>	6.9x10 <sup>4</sup>	4.4x10 <sup>4</sup>	1.4x10 <sup>5</sup>	<10	<10	<10	<10
<i>A. niger</i> + <i>Penicillium sp.</i>	1.4x10 <sup>4</sup>	1.5x10 <sup>4</sup>	1.3x10 <sup>4</sup>	5.9x10 <sup>4</sup>	2.2x10 <sup>3</sup>	<10	<10	<10

## Oil in Water Lotion (KKL-9-159) Base Formulation

pH: 6.2

% water: 72.2%; A<sub>w</sub>: n/a

Ingredient	%
<b>Phase A</b>	
DI-Water	q.s. to 100
Sodium Borate	0.30
Glycerin	6.00
Xanthan Gum	0.50
Sucrose Stearate	0.50
<b>Phase B</b>	
Mineral Oil	15.00
Stearic Acid	3.00
Vitamin E Acetate	0.50
Beeswax	2.00

## Test Results

### Colony Forming Units per Gram (CFU/g)

Test Organism	Unpreserved Control				Test-Mikrokill® COS (0.75%)			
	Initial Challenge			Rechallenge	Initial Challenge			Rechallenge
	24 hrs	7 days	21 days	21 days	24 hrs	7 days	21 days	21 days
<i>S. aureus</i>	1.5x10 <sup>6</sup>	2.3x10 <sup>6</sup>	4.5x10 <sup>3</sup>	7.9x10 <sup>3</sup>	2.3x10 <sup>4</sup>	9.3x10 <sup>3</sup>	6.8x10 <sup>2</sup>	3.0x10 <sup>2</sup>
<i>P. aeruginosa</i> + <i>B. cepacia</i>	3.5x10 <sup>6</sup>	4.0x10 <sup>6</sup>	2.8x10 <sup>7</sup>	<10 <sup>8</sup>	<10	<10	<10	<10
<i>K. pneumoniae</i>	3.0x10 <sup>6</sup>	2.9x10 <sup>7</sup>	7.2x10 <sup>7</sup>	7.4x10 <sup>7</sup>	<10	<10	<10	<10
<i>C. albicans</i>	6.4x10 <sup>4</sup>	8.9x10 <sup>4</sup>	4.8x10 <sup>4</sup>	3.8x10 <sup>7</sup>	9.0x10 <sup>3</sup>	<10	<10	<10
<i>A. niger</i> + <i>Penicillium sp.</i>	3.6x10 <sup>4</sup>	2.1x10 <sup>5</sup>	2.2x10 <sup>5</sup>	3.8x10 <sup>7</sup>	3.4x10 <sup>4</sup>	1.1x10 <sup>3</sup>	<10	<10

# Formulation Recommendations

- Can be easily added directly to the oil phase of the formulation during pre- or post-emulsification < 60°C
- For highly aqueous systems, co-solvents, coupling agents and/or surfactants may be needed to assist with solubilization. Mix 1:1 with Glycosperse® L-20 or Lonzet® SML-20 and add to finished product
- Compatible with most personal care ingredients
- pH: 2–8

## Global Regulatory

### Europe

- Approved under Annex V to Regulation EC/1223/2009
- Max concentration of 1% Phenoxyethanol and 0.3% Chlorphenesin

### Japan

- All ingredients approved (JNCI)
- Max concentration of 1% Phenoxyethanol and 0.3% Chlorphenesin
- Not permitted for products coming into contact with mucous membranes

### United States

- All ingredients allowed (CIR/CTFA)
- Max concentration of 1% Phenoxyethanol and 0.3% Chlorphenesin

### General

- Phenoxyethanol & Chlorphenesin - classified as preservatives
- Caprylyl Glycol
  - Officially/legally classified as an emollient
  - Not recognized and classified as a preservative
  - Antimicrobial synergistic activity becoming recognized

Typical Properties	
Appearance	Liquid water - white to straw
Color (Gardner)	2 max.
Odor	Characteristic

### USA

Lonza Consumer Care  
70 Tyler Place  
South Plainfield, NJ 07080  
Tel +1 908 561 5200

### Switzerland

Lonza Ltd  
Muenchensteinerstrasse 38  
4002 Basel  
Tel +41 61 316 81 11

Review and follow all product safety instructions. All product information corresponds to Lonza's knowledge on the subject at the date of publication, but Lonza makes no warranty as to its accuracy or completeness and Lonza assumes no obligation to update it. Product information is intended for use by recipients experienced and knowledgeable in the field, who are capable of and responsible for independently determining the suitability of ingredients for intended uses and to ensure their compliance with applicable law. Proper use of this information is the sole responsibility of the recipient. This information relates solely to the product as an ingredient. It may not be applicable, complete or suitable for the recipient's finished product or application; therefore republication of such information or related statements is prohibited. Information provided by Lonza is not intended and should not be construed as a license to operate under or a recommendation to infringe any patent or other intellectual property right. No claims are made herein for any specific intermediate or end-use application.

© 2017 Lonza

[www.lonzapreservation.com](http://www.lonzapreservation.com)  
[www.lonza.com/personalcare](http://www.lonza.com/personalcare)